

## Shower Seats

### Seats

Triangle	16" x 16"	PF-402
Triangle	23" x 23"	PF-403
Triangle-Convex	16" x 16"	PF-404
Square	12" x 12"	PF-410
Bench	11.5" x 35"	PF-420
Custom	Call for quote	
Note: All seats are 20" high		

We'll save you a seat. PreFormed Seats are sturdy and waterproof, made of high-density polystyrene and a latex polymer liquid waterproof coating. These seats install in a fraction of the time required for traditional methods.



#### **PreFormed Shower Seat Installation:**

1. Dry fit the seat to be sure it fits snug against the walls. The walls must be square and plumb.
2. Remove seat and completely waterproof the wall and floor behind the seat with a liquid waterproof membrane. Allow the membrane to completely dry.
3. Apply a modified thinset to the wall and floor behind with a 1/2" x 1/2" square notched trowel. NOTE: on the wall,
4. trowel the mortar horizontally, slide the bench in the mortar using the NTCA trowel and error method, and embed into the mortar on the floor, achieving complete coverage.
4. Once the thinset is set, tape all of the seams of the bench with fiberglass reinforced mesh and liquid waterproof membrane. As an alternative, a polyurethane sealant can be used to seal all joints where the seat meets the walls and floor. Silicone sealant are never to be used.
5. Install tile using a modified thinset mortar. Mastic adhesives are never to be used.

**NOTE:** PreFormed Shower Seats are waterproof. It is important that the outside coating remains intact and undamaged. Do not cut the shower seat. This will void all warranties.