



*The Strength  
Behind the Beauty*

# PreFormed® Slopes



PreFormed Slopes are designed to create the UPC required slope under a waterproofing membrane. Slopes allow you to easily install the pan liner and mortar bed in one day.

PreFormed Slopes eliminate a day of prep and screeding required for a minimally sloped mortar bed that goes under a traditional shower pan liner.

## Slopes

PF-102

24" x 48"



*The Strength  
Behind the Beauty*

## Slope Installation

Measure and located center of shower pan drain. Measure from center of the drain to shower corners.

Cut pre-slope panels to length. Cut Slopes from the 1/4" edge toward the 3/4" edge.

Cut around drain flange and position all pieces.

Secure Slopes to subfloor with liquid waterproof membrane.

Using TCNA and membrane manufacturer's specified methods, install PVC pan liner, liquid applied waterproof membrane or other acceptable waterproof membrane over the Slopes and up the wall 3" above the curb.

Plug the inside of the drainpipe and fill the shower pan with water for 24 hours. Repair any leaks before proceeding.

Float a mortar bed on top of the waterproofing membrane.

